



- The following maintenance instructions are designed to minimise the cost factor, while ensuring that your floorcovering retains the optimum appearance and performance. The Supratec⁺ system reduces the intensity of cleaning and the use of chemicals, which helps minimise the effect on the environment, without compromising such key elements as hygiene and underfoot safety.
- Supratec⁺ with polyurethane is designed to resist soiling, which ensures that - even after transportation, installation and the period prior to handover - the intensity of construction clean can be significantly reduced. This will have a beneficial impact on the initial costs.



INITIAL CONSTRUCTION CLEAN

- Remove all loose debris.
- Remove surface dust and grit by sweeping or vacuuming.
- Apply a solution of neutral cleanser (or alkaline cleanser, dependent upon the level of soiling), diluted to the manufacturer's instructions, with a spray over the section to be cleaned. Leave for sufficient time to react with the soiling.
- Pick up the solution with a clean microfibre mop, using a continuous side-to-side motion. When the mop head becomes loaded, it will start streaking the floor. At this point the dirty mop head should be removed and placed into a laundry bag and a clean mop head fitted. The cycle should then be repeated until the whole floor is completed.
- The dirty mop heads should then be laundered, in preparation for reuse.



ROUTINE MAINTENANCE

DAILY

- Remove surface dust and grit by sweeping or vacuum.
- Apply a solution of neutral cleanser (or alkaline cleanser, dependent upon the level of grease or oily contaminates), diluted to the manufacturer's instructions, with a spray over the section to be cleaned. Leave for sufficient time to react with the soiling.
- Pick up the solution with a clean microfibre mop, using a continuous side-to-side motion. When the mop head becomes loaded, it will start streaking the floor. At this point the dirty mop head should be removed and placed into a laundry bag and a clean mop head fitted. The cycle should then be repeated until the whole floor is completed.
- The dirty mop heads should then be laundered, in preparation for reuse.
- This maintenance procedure has been designed to optimise the benefits of the Supratec⁺ system - the latest in proven cleaning technology. The maximum benefits are derived from this system by carrying out this quick and simple procedure on a daily basis, and by using clean equipment each time, to maximise dirt pick-up and eliminate streaking.
- More traditional mechanical cleaning methods can be used - full details are available from Polyflor.



APPLICATION OF A FLOOR DRESSING

- A floor dressing or maintainer containing polish should not be applied to Polysafe Corona or Astral & Design, as this may impair the slip resistance but, if in doubt, consult our Technical Support staff.



- Always follow the Health and Safety guidance provided.
REGULAR CLEANING IS MORE BENEFICIAL TO THE FLOORCOVERING AND MORE COST-EFFECTIVE THAN OCCASIONAL HEAVY CLEANING.

POLYFLOR LTD. PO BOX 3 RADCLIFFE NEW ROAD WHITEFIELD MANCHESTER M45 7NR UK
 TEL: +44 (0)161 767 1111 UK SALES DIRECT: +44 (0)161 767 1122 UK FAX: +44 (0)161 767 1128
 EXPORT FAX: +44 (0)161 767 1166 E-MAIL: INFO@POLYFLOR.COM WWW.POLYFLOR.COM
 UK SAMPLE REQUESTS: +44 (0)161 767 2551

James Halstead
 FLOORING



2006

POLYFLOR SUPRATEC⁺ RANGE

SAFETY FLOORING

FLOORCARE FOR
 POLYSAFE CORONA,
 POLYSAFE ASTRAL AND
 POLYSAFE DESIGN



POLYFLOR
 COVERING THE WORLD